

Model No.DLS111 Cordless Slide Compound Miter Saw



# Model No.DLS111 Cordless Slide Compound Miter Saw



# Model No.DLS111 Cordless Slide Compound Miter Saw

| Item No. | Parts No. | Description | Interchangeability | Q'ty | New/ Old | Note1 | Note2 |
|---|---|---|---|---|---|---|---|
| 001 | 265995-6 | Binding head tapping screw 4X18 | | 6 | | | |
| 002 | 183H70-3 | Handle set | | 1 | | | |
| C10 | 810486-8 | Caution label | | 1 | | | |
| 002 | | INC. 14 | | | | | |
| 003 | 632L09-2 | Switch unit | | 1 | | | |
| 004 | 813T75-8 | Cap label | | 1 | * | | |
| 004-1 | 818H48-4 | Cap label | < | 1 | | | |
| 005A | 183H92-3 | Cap set | | 1 | * | | |
| 005A | | INC. 4 | | | * | | |
| 005B | 183J85-2 | Cap set | | 1 | * | | |
| 005-1A | 183J85-2 | Cap set | O | 1 | * | | |
| 005-1A | | INC. 4 | | | * | | |
| 005-1B | 140G30-2 | Cap complete | < | 1 | | | |
| 005-2A | 140G30-2 | Cap complete | < | 1 | | | |
| 005-2A | | INC. 4 | | | | | |
| 006 | 457935-0 | Switch lever | | 1 | | | |
| 007 | 416356-5 | Lock off lever | | 1 | | | |
| 008 | 651083-9 | Switch C3XA-1PSPM | | 1 | | | |
| 009 | 231026-3 | Compression spring 4 | | 1 | | | |
| 010A | 213275-4 | O-ring 18 | | 1 | * | | |
| 010B | 213218-6 | O-ring 16 | | 1 | | | |
| 010-1A | 213218-6 | O-ring 16 | < | 1 | | | |
| 011 | 458079-9 | Switch cover | | 1 | | | |
| 012 | 620750-7 | Sub controller | | 1 | | | |
| 013 | 265995-6 | Binding head tapping screw 4X18 | | 3 | | | |
| 014 | 183H70-3 | Handle set | | 1 | | | |
| C10 | 810486-8 | Caution label | | 1 | | | |
| 014 | | INC. 2 | | | | | |
| 015 | 451037-4 | Switch button | | 1 | | | |
| 016 | 451000-7 | Lead cover holder | | 1 | | | |
| 017 | 265995-6 | Binding head tapping screw 4X18 | | 1 | | | |
| 018 | 265995-6 | Binding head tapping screw 4X18 | | 2 | | | |
| 019 | 457933-4 | Rear cover | | 1 | | | |
| 020 | 620742-6 | Power supply circuit | | 1 | | | |
| 021 | 620728-0 | Controller | | 1 | * | | |
| 021-1 | 620H42-2 | Controller | < | 1 | | | |
| 022 | 813T74-0 | Indication label | | 1 | | | |
| 023 | 643874-2 | Terminal | | 2 | | | |
| 024 | 911948-0 | Pan head screw M6X80 WR | | 4 | | | |
| 025 | 853T07-3 | Name plate DLS111 | | 1 | | | |
| | | | | | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 026 | 457906-7 | Motor housing | | 1 | | | |
| 027 | 265995-6 | Binding head tapping screw 4X18 | | 3 | | | |
| 028 | 911273-9 | Pan head screw M5X50 WR | | 2 | | | |
| 029 | 183H65-6 | Battery housing set | | 1 | | | |
| C10 | 263005-3 | Rubber pin 6 | | 4 | | | |
| 029 | | INC. 30 | | | | | |
| 030 | 183H65-6 | Battery housing set | | 1 | | | |
| C10 | 263005-3 | Rubber pin 6 | | 4 | | | |
| 030 | | INC. 29 | | | | | |
| 031 | 629282-1 | Stator | | 1 | * | | |
| 031-1 | 629B80-5 | Stator | S | 1 | | | |
| 032 | 457934-2 | Baffle plate | | 1 | * | | |
| 032-1 | 413E35-6 | Baffle plate | O | 1 | | | |
| 033 | 265995-6 | Binding head tapping screw 4X18 | | 2 | | | |
| 034 | 211021-9 | Ball bearing 607LLB | | 1 | | | |
| 035 | 519454-5 | Rotor assembly | | 1 | * | | |
| 035 | | INC. 34 | | | * | | |
| 035-1 | 519454-5 | Rotor assembly | O | 1 | | | |
| 035-1 | | INC. 34 | | | | | |
| 036 | 319591-3 | Motor bracket | | 1 | | | |
| 037 | 961057-5 | Retaining ring (EXT) S-17 | | 1 | | | |
| 038 | 211275-8 | Ball bearing 6003DDW | | 1 | | | |
| 039 | 922331-6 | Hex. socket head bolt M6X20 W | | 1 | | | |
| 040 | 253804-1 | Flat washer 6 | | 1 | | | |
| 041 | 257163-5 | Ring 6 | | 1 | | | |
| 042 | 457704-9 | Dust nozzle | | 1 | * | | |
| 042-1 | 459250-8 | Dust nozzle | S | 1 | | | |
| 043 | 853T14-6 | Serial No. label DLS111 | | 1 | | | |
| 044 | 266026-4 | Binding head tapping screw 4X12 | | 1 | | | |
| 045 | 251554-2 | Thumb screw M6X40 | | 1 | | | |
| 046 | 922332-4 | Hex. socket head bolt M6X20 | | 1 | | | |
| 047 | 457667-9 | Logo plate | | 1 | | | |
| 048 | 961018-5 | Stop ring (EXT) E-5 | | 1 | | | |
| 049 | 251547-9 | Hex. socket head bolt M8X25 | | 1 | | | |
| 050 | 922226-3 | Hex. socket head bolt M5X18 W | | 1 | | | |
| 051 | 266034-5 | Binding head tapping screw 4X16 | | 3 | | | |
| 052 | 144529-7 | Link plate complete | | 1 | | | |
| 053 | 257163-5 | Ring 6 | | 1 | | | |
| 054 | 253804-1 | Flat washer 6 | | 1 | | | |
| 055 | 262001-8 | Urethane ring 5 | | 1 | * | | |
| 055-1 | 233343-7 | Compression spring 7 | S | 1 | | | |
| 056 | 942151-2 | Spring washer 6 | | 1 | * | | |
| 056-1 | 253428-3 | Spring washer 6 | O | 1 | | | |
| 057 | 257785-1 | Sleeve 6 | | 1 | | | |
| 058 | 266321-2 | Hex. socket set screw (flat point) M6X16 | | 1 | | | |
| 059 | 911114-9 | Pan head screw M4X10 WG | | 2 | | | |
| 060 | 232412-1 | Torsion spring 11 | | 1 | | | |
| 061 | 457764-1 | Dust guide plate | | 1 | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 062 | 161647-6 | Guard holder | | 1 | | | |
| 063 | 231928-3 | Ring spring 8 | | 1 | | | |
| 064 | 251544-5 | Hex. head shoulder bolt M4 | | 1 | | | |
| 065 | 144774-4 | Blade case complete | | 1 | | | |
| C10 | 263005-3 | Rubber pin 6 | | 3 | | | |
| C20 | 810064-4 | Caution label | | 1 | | | |
| C30 | 810354-5 | Laser beam label | | 1 | | | |
| 066 | 231240-1 | Compression spring 7 | | 1 | | | |
| 067 | 256633-1 | Collar HD. pin 6 | | 1 | | | |
| 068 | 457659-8 | Lead cover | | 1 | | | |
| 069 | 265028-7 | Pan head shoulder screw M4X11 | | 1 | * | | |
| 069-1 | 265D50-8 | Pan head screw M4X11 | O | 1 | * | | |
| 069-2 | 265028-7 | Pan head shoulder screw M4X11 | O | 1 | | | |
| 070 | 422155-5 | Guard | | 1 | | | |
| 071 | 347215-1 | Guard plate | | 1 | | | |
| 072 | 266283-4 | Hex. socket hex. head flange bol t M8X20 | | 1 | | | |
| 073 | 266020-6 | Binding head tapping screw 4X1 2 | | 1 | | | |
| 074 | 961052-5 | Retaining ring (EXT) S-12 | | 1 | | | |
| 075 | 210005-4 | Ball bearing 608DDW | | 1 | | | |
| 076 | 261104-5 | Rubber washer 12 | | 1 | | | |
| 077 | 253744-3 | Flat washer 12 | | 1 | | | |
| 078 | 254001-2 | Woodruff key 4 | | 1 | | | |
| 079 | 227550-2 | Spiral bevel gear 32 | | 1 | | | |
| 080 | 253744-3 | Flat washer 12 | | 1 | | | |
| 081 | 253313-0 | Thin washer 14 | | 1 | | | |
| 082 | 451002-3 | Grease holder | | 1 | | | |
| 083 | 266026-4 | Binding head tapping screw 4X1 2 | | 2 | | | |
| 084 | 325643-0 | Gear shaft | | 1 | | | |
| 085 | 216024-8 | Steel ball 4 | | 1 | | | |
| 086 | 227702-5 | Helical gear 27 | | 1 | | | |
| 087 | 227701-7 | Helical gear 14 | | 1 | | | |
| 088 | 210067-2 | Ball bearing 6000ZZ | | 1 | | | |
| 089 | 442147-8 | Gasket | | 1 | | | |
| 090 | 961055-9 | Retaining ring (EXT) S-15 | | 1 | | | |
| 091 | 210005-4 | Ball bearing 608DDW | | 1 | | | |
| 092 | 911223-4 | Pan head screw M5X16 WR | | 3 | | | |
| 093 | 227703-3 | Helical gear 28 | | 1 | | | |
| 094 | 267010-2 | Flat washer 5 | | 1 | | | |
| 095 | 210005-4 | Ball bearing 608DDW | | 1 | | | |
| 096 | 158957-0 | Bearing box complete | | 1 | | | |
| C10 | 263002-9 | Rubber pin 4 | | 1 | | | |
| 097 | 285847-5 | Bearing retainer 14-23 | | 1 | | | |
| 098 | 931202-6 | Hex. nut M5 | | 1 | | | |
| 099 | 942101-7 | Spring washer 5 | | 1 | * | | |
| 099-1 | 253427-5 | Spring washer 5 | O | 1 | | | |
| 100 | 325644-8 | Spindle | | 1 | | | |
| 101 | 211236-8 | Ball bearing 6002DDW | | 1 | | | |
| 102 | 285732-2 | Bearing retainer 51 | | 1 | | | |
| 103 | 224431-1 | Inner flange 53 | | 1 | | | |
| | | | | | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 104 | 224432-9 | Outer flange 53 | | 1 | | | |
| 105 | 257262-3 | Ring 16 | | 1 | | | |
| 106 | 265034-2 | Countersunk head screw M5X16 | | 2 | * | | |
| 106-1 | 265D49-3 | Countersunk head screw M5X16 | O | 2 | * | | |
| 106-2 | 265034-2 | Countersunk head screw M5X16 | O | 2 | | | |
| 107 | 266755-9 | Hex. socket head flange bolt M10X20 | | 1 | | | |
| 108 | 941051-3 | Flat washer 4 | | 2 | | | |
| 109 | 266020-6 | Binding head tapping screw 4X12 | | 2 | | | |
| 110 | 418104-8 | Lens | | 1 | | | |
| 111 | 419378-4 | Block B | | 1 | | | |
| 112 | 911003-8 | Pan head screw M3X6 WR | | 2 | | | |
| 113 | 231664-1 | Torsion spring 9 | | 1 | | | |
| 114 | 266318-1 | Hex. socket set screw (flat point) M4X6 | | 1 | | | |
| 115 | 266306-8 | Shoulder screw M5 | | 1 | | | |
| 116 | 419379-2 | Block C | | 1 | | | |
| 117 | 233471-8 | Compression spring 6 | | 1 | | | |
| 118 | 638651-5 | Laser circuit complete | | 1 | | | |
| 119 | 231664-1 | Torsion spring 9 | | 1 | | | |
| 120 | 266318-1 | Hex. socket set screw (flat point) M4X6 | | 1 | | | |
| 121 | 266229-0 | Hex. socket set screw (cup point) M5X8 | | 2 | | | |
| 122 | 457660-3 | Laser cover | | 1 | | | |
| 123 | 266034-5 | Binding head tapping screw 4X16 | | 2 | | | |
| 124 | 457664-5 | Protector | | 1 | | | |
| 125 | 265753-0 | Thumb screw M5X24 | | 1 | | | |
| 126 | 253807-5 | Flat washer 5 | | 1 | | | |
| 127 | 424193-3 | Roller | | 2 | | | |
| 128 | 266385-6 | Binding head tapping screw 4X14 | | 3 | | | |
| 129 | 457499-4 | Safety cover B | | 1 | | | |
| 130 | 266385-6 | Binding head tapping screw 4X14 | | 1 | | | |
| 131 | 347213-5 | Center plate | | 1 | | | |
| 132 | 231634-0 | Torsion spring 45 | | 1 | | | |
| 133 | 424190-9 | Cushion | | 1 | | | |
| 134 | 347214-3 | Center cover | | 1 | | | |
| 135 | 265985-9 | Hex. socket shoulder head bolt M6X9 | | 1 | | | |
| 136 | 253932-2 | Wave washer 10 | | 1 | | | |
| 137 | 210168-6 | Ball bearing 6805DDW | | 1 | | | |
| 138A | 457498-6 | Safety cover A | | 1 | * | | |
| 138-1A | 458437-9 | Safety cover A | S | 1 | | | |
| 138-1B | 458437-9 | Safety cover A | | 1 | | | |
| 139 | 126751-8 | Dust nozzle assembly | | 1 | * | | |
| 139 | | INC. 140-144,147,148 | | | * | | |
| 139-1 | 127427-0 | Dust nozzle assembly | S | 1 | * | | |
| C10 | 458939-5 | Button A | S | 1 | * | | |
| C20 | 232485-4 | Compression spring 5 | S | 1 | * | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 139-1 | | INC. 140-144,147,148 | | | * | | |
| 139-2 | 127427-0 | Dust nozzle assembly | O | 1 | | | |
| C10 | 458939-5 | Button A | | 1 | | | |
| C20 | 232485-4 | Compression spring 5 | | 1 | | | |
| 139-2 | | INC. 141-144,147 | | | | | |
| 140 | 265995-6 | Binding head tapping screw 4X18 | | 3 | * | | |
| 141 | 183H71-1 | Hose connector set | | 1 | * | | |
| 141 | | INC. 148 | | | * | | |
| 141-1 | 413J67-3 | Hose connector | S | 1 | | | |
| 142 | 245041-1 | Hose 28-0.45 | | 1 | | | |
| 143 | 457672-6 | Sleeve | | 1 | | | |
| 144 | 457673-4 | Stopper | | 1 | | | |
| 147 | 458198-1 | Hose joint | | 1 | * | | |
| 147-1 | 459249-3 | Hose joint | S | 1 | | | |
| 148 | 183H71-1 | Hose connector set | | 1 | * | | |
| 148 | | INC. 141 | | | * | | |
| 149 | 266034-5 | Binding head tapping screw 4X16 | | 3 | | | |
| 150 | 457665-3 | Sleeve 17 | | 2 | | | |
| 152 | 233537-4 | Torsion spring 35 | | 1 | | | |
| 153 | 251267-5 | Pan head shoulder screw M6 | | 1 | | | |
| 154 | 253948-7 | Wave washer 8 | | 1 | | | |
| 155 | 253835-0 | Flat washer 8 | | 1 | | | |
| 156 | 347221-6 | Stopper arm | | 1 | | | |
| 157 | 347222-4 | Front arm plate | | 1 | | | |
| 158 | 262076-7 | Felt ring 30 | | 2 | | | |
| 159 | 326994-4 | Rod 16 | | 1 | | | |
| 160 | 271437-0 | Knob 22 | | 1 | | | |
| 161 | 961013-5 | Stop ring (EXT) E-7 | | 1 | | | |
| 162 | 266034-5 | Binding head tapping screw 4X16 | | 4 | | | |
| 163 | 144531-0 | Front arm complete | | 1 | | | |
| C10 | 263005-3 | Rubber pin 6 | | 2 | | | |
| 164 | 233151-6 | Compression spring 4 | | 1 | | | |
| 165 | 256364-2 | Pin 4 | | 1 | | | |
| 166 | 232384-0 | Compression spring 10 | | 1 | | | |
| 167 | 326977-4 | Stopper pin | | 1 | | | |
| 168 | 457653-0 | Arm cover | | 1 | | | |
| 169 | 144658-6 | Holder complete | | 1 | | | |
| C10 | 812X89-8 | Operation label | | 1 | | | |
| 170 | 265008-3 | Flat head shoulder screw M5 | | 1 | | | |
| 171 | 222191-9 | Pulley 17-19.3 | | 1 | | | |
| 172 | 210167-8 | Ball bearing 6900LLB | | 1 | | | |
| 173 | 267804-5 | Wave washer 15 | | 1 | | | |
| 174 | 326975-8 | Shaft | | 1 | | | |
| 175 | 210167-8 | Ball bearing 6900LLB | | 1 | | | |
| 177 | 913416-9 | Hex. socket set screw (cup point) M8X12 | | 2 | | | |
| 178 | 416536-3 | Wrench holder | | 1 | | | |
| 179 | 266026-4 | Binding head tapping screw 4X12 | | 1 | | | |
| 180 | 951107-4 | Spring pin 4-14 | | 2 | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 181 | 273016-0 | Grip 50B | | 1 | | | |
| 182 | 265919-2 | Hex. socket head bolt M5X30 | | 1 | | | |
| 183 | 251545-3 | Hex. head shoulder bolt M6 | | 1 | | | |
| 184 | 144657-8 | Stopper lever complete | | 1 | | | |
| C10 | 812X87-2 | Operation label | | 1 | | | |
| 185 | 253948-7 | Wave washer 8 | | 1 | | | |
| 186 | 253835-0 | Flat washer 8 | | 1 | | | |
| 187 | 251267-5 | Pan head shoulder screw M6 | | 1 | | | |
| 188 | 326987-1 | Pin 9-365 | | 1 | | | |
| 189 | 253194-2 | Flat washer 5 | | 1 | | | |
| 190 | 257426-9 | Sleeve 5 | | 1 | | | |
| 191 | 253165-9 | Flat washer 8 | | 1 | | | |
| 192 | 457666-1 | Sleeve 20 | | 1 | | | |
| 193 | 326977-4 | Stopper pin | | 1 | | | |
| 194 | 222192-7 | Pulley 17-87.8 | | 1 | | | |
| 195 | 326980-5 | Hex. lock nut M10-19 | | 1 | | | |
| 196 | 225101-5 | Synchro belt 15-756 | | 1 | | | |
| 197 | 232384-0 | Compression spring 10 | | 1 | | | |
| 198 | 253388-9 | Flat washer 10 | | 1 | | | |
| 199 | 252244-0 | Hex. lock nut M10-17 | | 1 | | | |
| 200 | 253024-7 | Flat washer 10 | | 1 | | | |
| 202 | 216413-7 | Thrust needle cage 1024 | | 1 | | | |
| 203 | 253024-7 | Flat washer 10 | | 1 | | | |
| 204 | 216413-7 | Thrust needle cage 1024 | | 1 | | | |
| 205 | 961013-5 | Stop ring (EXT) E-7 | | 1 | | | |
| 206 | 271437-0 | Knob 22 | | 1 | | | |
| 207 | 253024-7 | Flat washer 10 | | 1 | | | |
| 208 | 144530-2 | Arm complete | | 1 | | | |
| C10 | 812X88-0 | Operation label | | 1 | | | |
| 209 | 251547-9 | Hex. socket head bolt M8X25 | | 1 | | | |
| 210 | 457871-0 | Indication plate R | | 1 | | | |
| 211 | 266026-4 | Binding head tapping screw 4X12 | | 1 | | | |
| 212 | 266034-5 | Binding head tapping screw 4X16 | | 4 | | | |
| 213 | 415208-7 | Release button | | 1 | | | |
| 214 | 233031-6 | Compression spring 12 | | 1 | | | |
| 215 | 457654-8 | Dust guide holder | | 1 | | | |
| 216 | 457870-2 | Pointer L | | 1 | | | |
| 217 | 266026-4 | Binding head tapping screw 4X12 | | 1 | | | |
| 218 | 253389-7 | Washer 94 | | 1 | | | |
| 219 | 422156-3 | Dust guide | | 1 | | | |
| 220 | 319593-9 | Stopper | | 1 | | | |
| 221 | 231646-3 | Torsion spring 14 | | 1 | | | |
| 222 | 253744-3 | Flat washer 12 | | 1 | | | |
| 223 | 961052-5 | Retaining ring (EXT) S-12 | | 1 | | | |
| 224 | 266026-4 | Binding head tapping screw 4X12 | | 2 | | | |
| 225 | 457668-7 | Holder | | 2 | | | |
| 226 | 144650-2 | Upper fence R complete | | 1 | | | |
| C10 | 810503-4 | Caution label | | 1 | | | |
| 227 | 144646-3 | Upper fence L complete | | 1 | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| C10 | 810503-4 | Caution label | | 1 | | | |
| 228 | 922458-2 | Hex. socket head bolt M8X35 WR | | 4 | | | |
| 229 | 251887-5 | Thumb screw M6X10 | | 2 | | | |
| 230 | 251561-5 | Hex. socket set screw (flat point) M10X12 | | 2 | | | |
| 231 | 319565-4 | Guide fence | | 1 | | | |
| 232 | 266026-4 | Binding head tapping screw 4X12 | | 4 | | | |
| 233 | 451013-8 | Kerf board | | 2 | | | |
| 235 | 265442-7 | Hex. head bolt M8X40 | | 1 | | | |
| 236 | 253852-0 | Flat washer 8 | | 2 | | | |
| 237 | 216413-7 | Thrust needle cage 1024 | | 1 | | | |
| 239 | 812X86-4 | Bevel scale label | | 1 | | | |
| 240 | 251547-9 | Hex. socket head bolt M8X25 | | 1 | | | |
| 241 | 251547-9 | Hex. socket head bolt M8X25 | | 1 | | | |
| 243 | 813L22-1 | Caution label | | 2 | | | |
| 244 | 266026-4 | Binding head tapping screw 4X12 | | 2 | | | |
| 245 | 457702-3 | Pointer | | 2 | | | |
| 246 | 326970-8 | Lock pin 8 | | 1 | | | |
| 247 | 234122-6 | Compression spring 6 | | 1 | | | |
| 249 | 457657-2 | Lever 25 | | 1 | | | |
| 250 | 253804-1 | Flat washer 6 | | 1 | | | |
| 251 | 961018-5 | Stop ring (EXT) E-5 | | 2 | | | |
| 252 | 144654-4 | Turn base complete | | 1 | | | |
| 252 | | INC. 239,243,253 | | | | | |
| 253 | 812X85-6 | Caution label | | 1 | | | |
| 254 | 326973-2 | Rod 12 | | 1 | | | |
| 255 | 286039-9 | Cap | | 2 | | | |
| 256 | 326976-6 | Center shaft | | 1 | | | |
| 257 | 911113-1 | Pan head screw M4X10 WR | | 2 | | | |
| 258 | 231325-3 | Compression spring 6 | | 1 | | | |
| 259 | 310803-7 | Turn stopper | | 1 | | | |
| 260 | 347217-7 | Lever plate | | 1 | | | |
| 261 | 256186-0 | Pin 5 | | 1 | | | |
| 262 | 911231-5 | Pan head screw M5X20 W | | 2 | | | |
| 263 | 347219-3 | Stopper holder | | 1 | | | |
| 264 | 326971-6 | Lock rod | | 1 | | | |
| 265 | 457656-4 | Lock lever | | 1 | | | |
| 266 | 326969-3 | Lock pin 6 | | 1 | | | |
| 267 | 256158-5 | Pin 3 | | 1 | | | |
| 268 | 231325-3 | Compression spring 6 | | 1 | | | |
| 269 | 347237-1 | Cam plate | | 1 | | | |
| 270 | 319592-1 | Pin holder | | 1 | | | |
| 271 | 922231-0 | Hex. socket head bolt M5X20 W | | 2 | | | |
| 272 | 347216-9 | Lock plate | | 1 | | | |
| 274 | 326972-4 | Rod 6 | | 1 | | | |
| 275 | 961011-9 | Stop ring (EXT) E-4 | | 1 | | | |
| 276 | 257425-1 | Ring 5 | | 2 | | | |
| 277 | 253194-2 | Flat washer 5 | | 2 | | | |
| 278 | 922231-0 | Hex. socket head bolt M5X20 W | | 2 | | | |
| 279 | 911113-1 | Pan head screw M4X10 WR | | 1 | | | |
| | | | | | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 280 | 144656-0 | Lever 25 complete | | 1 | | | |
| C10 | 263005-3 | Rubber pin 6 | | 1 | | | |
| 281 | 911008-8 | Pan head screw M3X8 WR | | 1 | | | |
| 282 | 345272-3 | Lock lever plate | | 1 | | | |
| 283 | 273015-2 | Grip 50A | | 1 | | | |
| 284 | 266026-4 | Binding head tapping screw 4X12 | | 2 | | | |
| 285 | 457655-6 | Slide plate | | 1 | | | |
| 286A | 347223-2 | Miter scale plate | | 1 | * | | |
| 286-1A | 347412-9 | Miter scale plate | < | 1 | | | |
| 286-1B | 347412-9 | Miter scale plate | | 1 | | | |
| 287 | 251546-1 | Pan head shoulder screw M5 | | 4 | | | |
| 288 | 347218-5 | Miter lock plate | | 1 | | | |
| 289 | 265786-5 | Thumb screw M5X16 | | 2 | | | |
| 290A | 319560-4 | Base | | 1 | * | | |
| 290-1A | 310891-4 | Base | O | 1 | * | | |
| 290-1B | 310891-4 | Base | | 1 | * | | |
| 290-2 | 310891-4 | Base | S | 1 | | | |
| 291 | 421845-7 | Foot | | 4 | | | |
| 292 | 267195-4 | Flat washer 4 | | 4 | | | |
| 293 | 266026-4 | Binding head tapping screw 4X12 | | 4 | | | |
| 294 | 326978-2 | Holder 200 | | 2 | * | | |
| 294-1 | 327095-1 | Holder 200 | S | 2 | | | |
| 295 | 961015-1 | Stop ring (EXT) E-9 | | 2 | | | |
| 296 | 266026-4 | Binding head tapping screw 4X12 | | 1 | | | |
| 297 | 266318-1 | Hex. socket set screw (flat point) M4X6 | | 1 | | | |
| 298A | 931102-0 | Hex. nut M4 | | 1 | * | | |
| 299 | 620L22-2 | Controller B | S | 1 | | | |
| 300 | 638A38-7 | Lead unit | S | 1 | | | |
| 301 | 652119-7 | Pan head screw M2X6 | S | 6 | | | |
| 302 | 941152-7 | Flat washer 6 | S | 1 | | | |
| A01 | 122852-0 | Dust bag assembly | | 1 | | | |
| C10 | 410602-8 | Fastener | | 1 | | | |
| A02 | 126617-2 | Vise assembly | | 1 | | | |
| A03 | 762001-3 | Triangular rule | | 1 | | | |
| A04 | 783208-8 | Hex. wrench 2.5 | | 1 | | | |
| A05A | 198897-0 | Wireless unit set | | 1 | * | | |
| A05-1A | 198900-7 | Wireless unit set | | 1 | * | | |
| A05-2A | 198900-7 | Wireless unit set | < | 1 | * | | |
| A05-3A | 198900-7 | Wireless unit set | < | 1 | * | | |
| A05-4A | 198900-7 | Wireless unit set | O | 1 | * | | |
| A05-5A | 198900-7 | Wireless unit set | < | 1 | | | |
| A06 | B-14261 | T.C.T. SAW BLADE 260X30X40T | | 1 | * | | |
| A06-1 | B-64630 | TCT BLADE260X45T WOOD EFFIC | O | 1 | * | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| | | UT | | | | | |
| A06-2 | E-27763 | TCT SAW EFFI 260X45T | < | 1 | | | |
| A07 | 781044-6 | Hex. wrench 6 | | 1 | | | |
| F02 | 192628-9 | Crown molding stopper set | | 1 | | | |
| F04 | 198688-9 | Stand set | | 1 | | | |
| F05-1 | 198687-1 | Stand set | < | 1 | | | |
| F08 | 191C01-8 | Sub base assembly set | | 1 | | | |

Please state Parts No. when your order.

Print Date 05/11/2026