
Model No.DST630 Cordless Narrow Crown Stapler



Model No.DST630 Cordless Narrow Crown Stapler

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/ Old	Note1	Note2
001	911243-8	Pan head screw M5X25 WR		1			
002	266130-9	Binding head tapping screw 3X16		11			
003	1831E0-7	Housing set		1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	252103-8	Hex. lock nut M5-8		1			
003		INC. 21					
004	632V61-0	Switch unit		1			
005	232889-0	Leaf spring		1			
006	650060-8	Switch C3JR-5BM-PAND-2		1			
007	232884-0	Compression spring 7		1			
008	4130V7-5	Trigger		1	*		
008-1	1413L6-2	Trigger complete	O	1			
009	654908-6	Terminal		1			
010	232876-9	Compression spring 7		2			
011	652069-6	Flat head screw M3X6		3			
012	620P18-7	Controller		1			
013	266490-9	Pan head tapping screw 2X6		3			
014	629A28-1	Stator		1			
015	210231-5	Ball bearing 625ZZ		1			
016	519865-4	Rotor assembly		1			
016		INC. 15,17					
017	210005-4	Ball bearing 608DDW		1			
018	4130V8-3	LED holder		1			
019	620P87-8	LED circuit		1			
020	266007-8	Binding head tapping screw 3X10		2			
021	1831E0-7	Housing set		1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	252103-8	Hex. lock nut M5-8		1			
021		INC. 3					
022	620P99-1	Switch circuit complete		1			
023	327D23-0	Valve cap		1			
024	213007-9	O-ring 8		1			
025	243138-0	Valve core		1			
026	312H24-5	Top cap		1			
027	922232-8	Hex. socket head bolt M5X20		4			
028	213A78-2	X-ring 23		1	*		
028-1	213B07-1	X-RING 23	<	1			
029	4130T8-9	Slide ring		2			
030	137286-4	Driver assembly		1	*		
030-1	137286-4	Driver assembly	O	1			
031	8149C6-5	Name plate DST630		1			
032	8149C8-1	Serial No. label DST630		1			
033	259092-8	Spiral retaining ring (EXT) 36		1			
034	422B82-8	Seal ring		1			

035	141Y40-0	Chamber complete		1			
036	213479-8	O-ring 33		2	*		
036-1	213A95-2	O-RING 33	<	2			
037	327E19-7	Cylinder		1			
038	422B80-2	Front cushion		1			
039	122G77-8	Gear assembly		1			
040	227B71-6	Spur gear 14		4			
041	141Y39-5	Carrier complete		1			
042	210168-6	Ball bearing 6805DDW		1			
043	265E16-4	Tapping screw 4X18		2			
044	911002-0	Pan head screw M3X6		1			
045	620P94-1	Sensor circuit		1			
046	1411R3-8	Inner housing complete		1			
047	265E16-4	Tapping screw 4X18		4			
048	347C87-2	Flat washer 10		1			
049	961006-2	Retaining ring (EXT) S-10		1			
050	162D48-5	Holder complete		1			
051	347C92-9	Lifter plate		1			
052	327E17-1	Lifter		1			
053	268054-5	Pin 4		6			
054	234227-2	Compression spring 3		1			
055	327E18-9	Lifter shaft		1			
056	211391-6	Ball bearing 6900LLU		1			
057	4130X3-7	Lifter cap		1			
058	911102-6	Pan head screw M4X6		1			
059	347C90-3	Magazine stopper		1			
060	327E20-2	Guide shaft		2			
061	232892-1	Compression spring 4		2			
063	137287-2	Magazine assembly		1			
C10	8085R1-6	Caution label		1			
063		INC. 58-61,64-75					
064	4130W6-4	Leaf spring		1			
065	347C89-8	Pusher		1			
066	4130X1-1	Pusher guide		1			
067	951069-6	Spring pin 3-20		1			
068	4130X2-9	Lock lever		1			
069	232891-3	Compression spring 6		1			
070	4130W9-8	Magazine end		1			
071	232893-9	Compression spring 3		1			
072	347C91-1	Plate		1			
073	266130-9	Binding head tapping screw 3X16		1			
074	951063-8	Spring pin 3-16		1			
075	162D47-7	Sub magazine		1			
077	232882-4	Compression spring 9		1			
078	140W22-7	Switch complete		1			
079	232883-2	Leaf spring		1			
080	141Y69-6	Adjuster complete		1			
081	213021-5	O-ring 5		1			
082	961017-7	Stop ring (EXT) E-3		1			
083	347C93-7	Contact arm		1			
084	422B94-1	Nose adapter		1			

085	313614-9	Driver guide		1			
086	922148-7	Hex. socket head bolt M4X25 WR		4			
087	313577-9	Driver guide cover		1			
A01	251314-2	Truss head screw M4X12		1			
A02	346317-0	Hook		1			
A03A	422B94-1	Nose adapter		2			
A03B	821551-8	Connector plastic case (type 3)		1			
C10	453974-8	Latch		4			
A04B	836306-8	Inner tray		1			
A05B	***DC18RC	DC18RC FAST CHARGER		1			
A05B		COMPO-PARTS					
A06B	450128-8	Battery cover		1			
A07B	197600-6	Battery BL1830B set		2			
A08B	422B94-1	Nose adapter		2			

Please state Parts No. when your order.

Print Date 06/01/2026