
Model No.DUS108 Cordless Garden Sprayer



# Model No.DUS108 Cordless Garden Sprayer

| Item No. | Parts No. | Description | Interchangeability | Q'ty | New/ Old | Note1 | Note2 |
|---|---|---|---|---|---|---|---|
| 001 | PR00000319 | HARNESS LR SET | | 1 | | | |
| 002 | PR00000251 | SINGLE NOZZLE ASSY | | 1 | | | |
| 002 | | INC. 3-5 | | | | | |
| 003 | PR00000252 | CAP NUT | | 1 | | | |
| 004 | PR00000253 | SPRAYER NOZZLE | | 1 | | | |
| 005 | PR00000254 | O-RING 12X2 | | 1 | | | |
| 006 | PR00000255 | TWIN HEAD MIST NOZZLE ASSY | | 1 | | | |
| 006 | | INC. 7-9 | | | | | |
| 007 | PR00000256 | CAP NUT | | 2 | | | |
| 008 | PR00000257 | SPRAY CORE | | 2 | * | | |
| 008-1 | PR00000257 | SPRAY CORE | O | 2 | * | | |
| 008-2 | PR00000258 | DISK | X | 1 | * | | |
| 008-3 | PR00000258 | DISK | O | 2 | | | |
| 009 | PR00000258 | DISK | | 2 | * | | |
| 009-1 | PR00000258 | DISK | O | 2 | * | | |
| 009-2 | PR00000257 | SPRAY CORE | X | 1 | * | | |
| 009-3 | PR00000257 | SPRAY CORE | O | 2 | | | |
| 010 | PR00000260 | SPRAY WAND ASSY | | 1 | | | |
| 010 | | INC. 11,12 | | | | | |
| 011 | PR00000259 | GASKET 11.5 | | 1 | | | |
| 012 | PR00000186 | O RING 6X2 | | 1 | | | |
| 013 | PR00000314 | HOOK FOR SPRAY WAND | | 1 | | | |
| 014 | PR00000263 | RUBBER CAP | | 1 | | | |
| 015 | PR00000264 | SPRAY WAND THREAD ADAPTOR | | 1 | | | |
| 016 | PR00000147 | FILTER ASSEMBLY | | 1 | | | |
| 016 | | INC. 17 | | | | | |
| 017 | PR00000146 | O SEAL RING 4.5X1.5 | | 1 | | | |
| 018 | PR00000266 | HOSE WITH SWITCH ASSY | | 1 | * | | |
| 018 | | INC. 19-22,25,26 | | | * | | |
| 018-1 | PR00000501 | HOSE WITH SWITCH ASSY | S | 1 | | | |
| 018-1 | | INC. 19-22,25,26 | | | | | |
| 019 | PR00000152 | LOCK COVER | | 1 | | | |
| 020 | PR00000254 | O-RING 12X2 | | 1 | | | |
| 021 | PR00000150 | SPRING | | 1 | | | |
| 022 | PR00000151 | VALVE ROD | | 1 | | | |
| 022 | | INC. 23,24 | | | | | |
| 023 | PR00000205 | O RING 3X1.5 | | 1 | | | |
| 024 | PR00000205 | O RING 3X1.5 | | 1 | | | |
| 025 | PR00000186 | O RING 6X2 | | 1 | | | |
| 026 | PR00000149 | O RING 8X1.8 | | 1 | | | |
| 027 | PR00000182 | TAPPINNG SCREW ST2.9X12 | | 1 | | | |
| 028 | PR00000153 | HANDLE SET | | 1 | * | | |
| 028-1 | PR00000502 | HANDLE SET | < | 1 | | | |
| 029 | PR00000148 | HANDLE TRIGGER ASSEMBLY | | 1 | | | |
| 030 | PR00000182 | TAPPINNG SCREW ST2.9X12 | | 5 | | | |
| 031 | PR00000316 | TANK LID | | 1 | * | | |
| 031-1 | PR00000485 | TANK LID(W/SEAL RING) | S | 1 | | | |
| | | | | | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 032 | PR00000315 | TANK LID SEALING LID | S | 1 | * | | |
| 033 | PR00000313 | TANK FILTER | | 1 | | | |
| 034 | PR00000478 | 10L TANK | | 1 | * | | |
| 034 | | INC. 35 | | | * | | |
| 034-1 | PR00000513 | 10L TANK | < | 1 | | | |
| 034-1 | | INC. 35 | | | | | |
| 035 | PR00000355 | 10L MODEL LABEL | | 1 | | | |
| 036 | PR00000312 | DRAIN PLUG ASSY | | 1 | | | |
| 036 | | INC. 37 | | | | | |
| 037 | PR00000479 | O-RING 21.2X2.65 | | 1 | | | |
| 038 | PR00000259 | GASKET 11.5 | | 1 | | | |
| 039 | PR00000265 | TANK ELBOW JOINT | | 1 | | | |
| 040 | PR00000280 | TUBE 8X230 | | 1 | | | |
| 041 | PR00000279 | SUCTION HEAD | | 1 | | | |
| 042 | PR00000278 | NET FILTER FOR SUCTION HEAD | | 1 | | | |
| 043 | PR00000277 | O-RING 17.5X3 | | 1 | | | |
| 044 | PR00000262 | PLASTIC NUT 1/2" | | 1 | | | |
| 045 | PR00000261 | HOSE CLIP | | 1 | | | |
| 046 | PR00000287 | SUCTION TUBE SET | | 1 | | | |
| 046 | | INC. 47-53,63-65,78,80 | | | | | |
| 047 | PR00000281 | TUBE 6X140 | | 1 | | | |
| 048 | PR00000282 | SPRING 5X127 | | 1 | | | |
| 049 | PR00000261 | HOSE CLIP | | 1 | | | |
| 050 | PR00000283 | CHECK VALVE ASSEMBLY | | 1 | | | |
| 051 | PR00000261 | HOSE CLIP | | 1 | | | |
| 052 | PR00000284 | TUBE 6X55 | | 1 | | | |
| 053 | PR00000184 | SNAPPER HOSE CLAMP (L) | | 1 | | | |
| 054 | PR00000270 | PUMP UNIT WITH MOTOR | | 1 | * | | |
| 054 | | INC. 55 | | | * | | |
| 054-1 | PR00000573 | PUMP UNIT WITH MOTOR | O | 1 | | | |
| 054-1 | | INC. 55 | | | | | |
| 055 | PR00000268 | ANTI VIBRATION RING | | 1 | | | |
| 056 | PR00000292 | ANTI VIBRATION PAD | | 2 | | | |
| 057 | PR00000272 | MOTOR FIXED PLATE | | 1 | | | |
| 058 | PR00000271 | TAPPING SCREW ST4.0X16 | | 2 | | | |
| 059 | PR00000274 | RUBBER SHEET | | 1 | | | |
| 060 | PR00000273 | PUMP FIXED PLATE | | 1 | | | |
| 061 | PR00000271 | TAPPING SCREW ST4.0X16 | | 2 | | | |
| 062 | PR00000267 | SNAPPER HOSE CLAMP (M) | | 1 | | | |
| 063 | PR00000275 | TUBE 6X90 | | 1 | | | |
| 064 | PR00000276 | SPRING | | 1 | | | |
| 065 | PR00000267 | SNAPPER HOSE CLAMP (M) | | 1 | | | |
| 066 | PR00000155 | GROMMET | | 1 | | | |
| 067 | PR00000184 | SNAPPER HOSE CLAMP (L) | | 1 | | | |
| 068 | PR00000267 | SNAPPER HOSE CLAMP (M) | | 1 | | | |
| 069 | PR00000341 | DUS108 NAME PLATE EU | | 1 | | | |
| 070 | PR00000354 | WARNING LABEL | | 1 | | | |
| 071 | PR00000472 | PUMP HOUSING ASSY EU | | 1 | * | | |
| 071 | | INC. 70,72 | | | * | | |
| 071-1 | PR00000522 | PUMP HOUSING ASSY EU | < | 1 | | | |
| 071-1 | | INC. 70,72 | | | | | |
| 072 | PR00000290 | SEALING STRIP | | 1 | | | |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 073 | PR00000288 | PAN HEAD SCREW M5X12 WITH WR | | 2 | | | |
| 074 | PR00000288 | PAN HEAD SCREW M5X12 WITH WR | | 2 | | | |
| 075 | PR00000271 | TAPPING SCREW ST4.0X16 | | 1 | | | |
| 076 | PR00000289 | BACK PAD | | 1 | | | |
| 077 | PR00000288 | PAN HEAD SCREW M5X12 WITH WR | | 4 | | | |
| 078 | PR00000285 | BASE | | 1 | | | |
| 079 | PR00000271 | TAPPING SCREW ST4.0X16 | | 2 | | | |
| 080 | PR00000286 | KNOB LOCK CAP ASSEMBLY | | 1 | | | |
| 080 | | INC. 81,82 | | | | | |
| 081 | PR00000186 | O RING 6X2 | | 1 | | | |
| 082 | PR00000475 | KNOB LOCK CAP STRAP | | 1 | | | |
| 083 | PR00000295 | PCB | | 1 | | | |
| 084 | PR00000293 | TAPPING SCREW ST2.9X10 | | 2 | | | |
| 085 | PR00000271 | TAPPING SCREW ST4.0X16 | | 4 | | | |
| 086 | PR00000297 | BATTERY HOUSING SET | | 1 | | | |
| 087 | PR00000302 | BATTERY TERMINAL | | 1 | | | |
| 088 | PR00000130 | DAM-BOARD | | 1 | | | |
| 089 | PR00000194 | SPRING | | 2 | | | |
| 090 | PR00000132 | TAPPING SCREW ST4.0X12 | | 2 | | | |
| 091 | PR00000288 | PAN HEAD SCREW M5X12 WITH WR | | 1 | | | |
| 092 | PR00000288 | PAN HEAD SCREW M5X12 WITH WR | | 1 | | | |
| 093 | PR00000288 | PAN HEAD SCREW M5X12 WITH WR | | 1 | | | |
| 094 | PR00000288 | PAN HEAD SCREW M5X12 WITH WR | | 1 | | | |
| 095 | PR00000307 | INDICATION LABEL | | 1 | | | |
| 096 | PR00000299 | SWITCH | | 1 | * | | |
| 096-1 | PR00000575 | SWITCH | O | 1 | | | |
| 097 | PR00000298 | SWITCH GASKET | | 1 | | | |
| 098 | PR00000300 | HEX NUT(SWITCH) | | 1 | | | |
| 099 | PR00000304 | BATTERY COVER CLIP | | 1 | | | |
| 100 | PR00000305 | BATTERY COVER | | 1 | | | |
| 101 | PR00000306 | SHAFT 3X136 | | 1 | | | |
| 102 | PR00000303 | BATTERY COVER SEAL PAD | | 1 | | | |
| A01 | PR00000317 | MEASURING CUP(ML) | | 1 | | | |
| F01 | AB45127080 | WEEDING NOZZLE WITH COVER | | 1 | | | |
| F02 | PR00000251 | SINGLE NOZZLE ASSY | | 1 | | | |
| F03 | PR00000255 | TWIN HEAD MIST NOZZLE ASSY | | 1 | | | |
| F04 | PR00000319 | HARNESS LR SET | | 1 | | | |
| F05 | PR00000578 | SPRAY WAND | | 1 | | | |