
Model No.HR004G Cordless Combination Hammer



Model No.HR004G Cordless Combination Hammer

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/ Old	Note1	Note2
001	199138-7	Tool holder set		1			
001		INC. 123-142					
010	126882-3	Grip assembly		1			
010		INC. 11-19					
011	144959-2	Lock button complete		1			
012	233360-7	Compression spring 4		1			
013	265625-9	Thumb screw M6X50		1			
014	422258-5	Sponge sheet		1			
015	458355-1	Side handle base		1			
016	931302-2	Hex. nut M6		1			
017	458357-7	Grip 36		1			
018	422255-1	Cap		1			
019	161838-9	Fix pin		1			
020	266351-3	Binding head tapping screw 4X35		4			
021	144965-7	Gear housing complete		1			
C10	213345-9	Oil seal 25		1			
C20	331890-3	Cup sleeve		1			
022	211294-4	Ball bearing 6806LLU		1			
023	211012-0	Ball bearing 606ZZ		1			
024	233360-7	Compression spring 4		1			
025	347228-2	Lock plate		1			
026	213278-8	O-ring 17		1			
027	135961-6	Change lever assembly		1			
027		INC. 26					
028	234264-6	Compression spring 3		1			
029	457709-9	Lock button		1			
031	216019-1	Steel ball 3		4	*		
031-1	216068-8	Steel ball 3	<	4			
031-1E	216068-8	Steel ball 3		4			
032	144966-5	Tool holder guide complete		1			
C10	213344-1	Oil seal 9		1			
033	332139-4	Driving flange		1			
034	227360-7	Spur gear 51		1			
035	234148-8	Compression spring 31		1			
036	267153-0	Flat washer 30		1			
037	257932-4	Spiro lock washer 30		1			
038	267153-0	Flat washer 30		1			
039	325783-4	Sleeve 9B		1			
040	325791-5	Impact bolt B		1			
041	325792-3	Washer 10		1			
042	234149-6	Compression spring 20		1			
043	325793-1	O-ring case B		1			
044	213073-6	O-ring 9		1			
045	233979-2	Ring spring 28		1			
046	325784-2	Striker		1			
047	213258-4	O-ring 17.5		1			

048	327079-9	Piston cylinder		1			
049	346036-8	Guide plate		1			
050	324215-8	Piston joint		1			
051	232449-8	Compression spring 14		1			
052	265A87-7	Hexalobular socket button head bolt M4X8		1	*		
052-1	265A87-7	Hexalobular socket button head bolt M4X8	O	1			
053	347344-0	Spring guide		1			
054	922148-7	Hex. socket head bolt M4X25 WR		2			
055	144960-7	Inner support complete		1			
056	257336-0	Stop ring (EXT) U-6		1			
057	253186-1	Flat washer 7		1			
058	226170-9	Spur gear 10		1			
059	332125-5	Clutch cam		2	*		
059-1	310678-4	Clutch cam	O	2			
059-1E	310678-4	Clutch cam		2			
060	327078-1	Cam shaft		1			
061	219030-2	Swash bearing 10		1			
062	257321-3	Ring 8		1			
063	346538-4	Weight holder guide		2			
064	253077-6	Flat washer 6		1			
065	961018-5	Stop ring (EXT) E-5		1			
066	310869-7	Counter weight		1			
067	922148-7	Hex. socket head bolt M4X25 WR		2			
068	319674-9	Bearing box		1			
069	211032-4	Ball bearing 608ZZ		1			
070	347343-2	Bearing retainer B		1			
071	221599-4	Spiral bevel gear 32		1			
072	213850-6	O-ring 74		1			
073	256536-9	Flat fillister HD. pin 6		1			
074	136194-6	Inner housing assembly		1			
074		INC. 52,53,72,76,78					
075	232436-7	Compression spring 10		1			
076	443153-6	Felt		1			
077	922118-6	Hex. socket head bolt M4X12 WR		2			
078	213008-7	O-ring 22.4		1			
079	347230-5	Change plate B		1			
080	234343-0	Compression spring 5		1			
081	347229-0	Change plate A		1			
082	346536-8	Bearing retainer A		1			
083	144964-9	Spiral bevel gear 11 complete		1			
084	210024-0	Ball bearing 608 LLU		1			
085	253835-0	Flat washer 8		1			
086	519513-5	Rotor assembly		1	*		
086		INC. 83-85,87			*		
086-1	619841-9	Rotor	O	1			
086-1		INC. 83-85,87					
086-1E	619841-9	Rotor		1			
086-1E		INC. 83-85,87					

087	210022-4	Ball bearing 626DDW		1			
088	629454-8	Stator		1			
089	652069-6	Flat head screw M3X6		3			
090	266490-9	Pan head tapping screw 2X6		3			
091	620B99-7	Controller		1	*		
091-1	620K80-2	Controller	<	1	*		
091-2	620P11-1	Controller	<	1			
091-2E	620P11-1	Controller		1			
097	127344-4	Hook assembly		1	*		
097-1	122B76-0	Hook assembly	<	1			
097-1E	122B76-0	Hook assembly		1			
098	911211-1	Pan head screw M5X12 W		2	*		
098-1	911218-7	Pan head screw M5X14 WR	<	2			
098-1E	911218-7	Pan head screw M5X14 WR		2			
103	264002-2	Square nut M5		2			
104	459184-5	Cushion ring 12		2			
105	183N56-3	Housing set		1			
105		INC. 112					
106	266326-2	Binding head tapping screw 4X18		8			
107	856N68-6	Name plate HR004G		1			
108	8008C4-9	Clear label		1	*		
110	346039-2	Support plate		1			
111	620549-0	LED circuit		1			
112	183N56-3	Housing set		1			
112		INC. 105					
113	233598-4	Torsion spring 6		1			
114	313226-8	Opener		1			
115	632P64-8	Terminal unit		1			
116	856N72-5	Serial No. label HR004G		1			
117	266326-2	Binding head tapping screw 4X18		7			
118	183N53-9	Handle set		1			
C10	263005-3	Rubber pin 6		2			
118		INC. 122					
119	453124-5	F/R change lever		1			
120	651439-6	Switch C3JR-4B-2		1			
121	8005T5-8	XGT logo label		1			
122	183N53-9	Handle set		1			
C10	263005-3	Rubber pin 6		2			
122		INC. 118					
123	286288-8	Cap 35		1			
124	233989-9	Ring spring 14		1			
125	346221-3	Washer 16		1			
126	233992-0	Ring spring 15		1			
127	267437-6	Flat washer 17		1			
128	424364-2	Rubber washer 16		1			
129	458358-5	Chuck cover		1			
130	327081-2	Stopper		1			
131	216022-2	Steel ball 7.0		2			

132	346177-0	Guide washer		1			
133	233916-6	Conical compression spring 21-29		1			
134	327080-4	Tool holder		1			
135	216013-3	Steel ball 6		2			
136	231669-1	Torsion spring 31		1			
137	345334-7	Change ring		1			
138	418218-3	Change cover		1			
139	216018-3	Steel ball 5.0		1			
140	345335-5	Leaf spring		1			
141	267270-6	Flat washer 24		1			
142	233924-7	Ring spring 21		1			
143	135965-8	Tool holder assembly		1	*		
143		INC. 31-45			*		
143-1	137275-9	Tool holder assembly	<	1			
143-1		INC. 31-45					
143-1E	137275-9	Tool holder assembly		1			
143-1E		INC. 31-45					
A01	331886-4	Depth gauge		1			
A02	198993-4	Grease vessel set		1			
A03	443122-7	Cloth		1	*		
A04	199139-5	Drill chuck set		1			
A05B	8008A3-7	Plastic case label HR004GM201		2			
A05C	8008A5-3	Plastic case label HR004GM202		2			
A05D	8007Y7-1	Plastic case label HR004GZ01		2			
A06B	8008A2-9	Indication label HR004GM201		1			
A06C	8008A4-5	Indication label HR004GM202		1			
A06D	8007Y6-3	Indication label HR004GZ01		1			
A07	821552-6	Connector plastic case (type 4)		1			
C10	453974-8	Latch		4			
A08	835C84-5	Inner tray		1			
A09	***DX14	DX14 DUST COLLECTION SYSTEM		1			
A09		COMPO-PARTS					
A09		INC. A10					
A10	424474-5	Sealing cap		5			
A11	191B26-6	Battery BL4040 set		2			
A11E	1917Y6-7	Battery BL4040F set		2			
A12B	412393-7	Battery cover		1	*		
A12	412393-7	Battery cover		1			
A12-1B	412393-7	Battery cover	<	2			
A13	***DC40RA	DC40RA FAST CHARGER		1			
A13		COMPO-PARTS					
B01	195833-7	Hammer service kit		1			
C10	195127-0	Oil vessel set		2			
B01		INC. 44,45,47,123,124,126,128,					
B01		INC. 131					
B01E	195833-7	Hammer service kit		1			
C10	195127-0	Oil vessel set		2			
B01E		INC. 44,45,47,123,124,126,128,					

B01E		INC. 131					
B02	191C37-7	Hook set		1	*		
B02		INC. 97,98,103			*		
B02-1	191W90-3	Hook set	<	1			
C10	911218-7	Pan head screw M5X14 WR		2			
B02-1		INC. 97,103					
B02-1E	191W90-3	Hook set		1			
C10	911218-7	Pan head screw M5X14 WR		2			
B02-1E		INC. 97,103					
F03	191C37-7	Hook set		1	*		
F07	191E60-4	Dust collection system set DX14		1			
F10	192877-8	Drill chuck 13 set		1			
F11	192892-2	Keyless drill chuck set		1			
F12	194041-7	Drill chuck set		1			
F13	194254-0	Keyless drill chuck set		1			
F14	194683-7	Grease vessel set		1			
F16	195548-6	Joint 22-38 set		1			
F18	198993-4	Grease vessel set		1			
F20	199555-1	Dust case set		1			
F21	199557-7	Filter set		1			
F40	199138-7	Tool holder set		1			
F41	199139-5	Drill chuck set		1			
F42	1917K7-7	Dust extractor attachment set		1			
F43	1918R1-4	SEALING CAP B SET		1			
F44	1918L7-0	DUST EXTRACTION PAD SET		1			
G12	1914X3-8	Dust extraction pad set		1			
G12E	1914X3-8	Dust extraction pad set		1			