
Model No.UM600D Cordless Grass Shear



Model No.UM600D Cordless Grass Shear

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/ Old	Note1	Note2
001	915116-7	Binding head screw M4X12		1			
002	144342-3	Protector complete		1	*		
C10	819948-3	Caution label		1	*		
002-1	140V97-0	Protector complete	<	1	*		
C10	819948-3	Caution label		1	*		
C11	819948-3	Caution label	<	1	*		
002-2	1410D3-4	Protector complete	O	1			
C12	8072W3-6	Caution label	O	1			
003	183G04-0	Housing set		1	*		
C10	931102-0	Hex. nut M4		1	*		
C20	263002-9	Rubber pin 4		2	*		
C30	346275-0	Plate		2	*		
003		INC. 27			*		
003-1	183U51-5	Housing set	S	1			
C10	931102-0	Hex. nut M4		1			
C20	263002-9	Rubber pin 4		2			
C30	346275-0	Plate		2			
003-1		INC. 27					
004	632K11-9	Controller unit		1	*		
C10	688131-1	Line filter		2	*		
004-1	632R78-9	Controller unit	<	1			
C10	688131-1	Line filter		2	*		
C11	688131-1	Line filter	O	2			
C20	654086-2	Receptacle 42486-2		2			
005	644813-5	Terminal		1			
006	452438-9	Lock off button		1	*		
006-1	413A16-6	Lock off button	S	1			
007	231473-8	Compression spring 4		1			
008	457534-8	Slide plate		1			
009	234339-1	Compression spring 6		1			
010	454879-5	Lock lever		1			
011	650744-8	Switch D3V-16-3C26		1			
012	231473-8	Compression spring 4		1			
013	417564-1	Switch lever		1			
016	451814-4	Dust guard		1			
017	268254-7	Pin 6		1			
018	253715-0	Flat washer 6		1			
019	268256-3	Flat fillister HD. pin 4		2			
020	135883-0	Helical gear 47 assembly		1			
020		INC. 19					
021	161598-3	Crank complete		1			
022	629258-8	DC motor		1			
023	268076-5	Pin 6		1			
024	253715-0	Flat washer 6		2			
025	226831-1	Gear 12-31		1			
027	183G04-0	Housing set		1	*		
C10	931102-0	Hex. nut M4		1	*		

C20	263002-9	Rubber pin 4		2	*		
C30	346275-0	Plate		2	*		
027		INC. 3			*		
027-1	183U51-5	Housing set	S	1			
C10	931102-0	Hex. nut M4		1			
C20	263002-9	Rubber pin 4		2			
C30	346275-0	Plate		2			
027-1		INC. 3					
028	266429-2	Binding head tapping screw 3X16		6			
029	853F88-3	Name plate UM600D		1	*		
029-1	852Y86-8	Name plate UM600D	<	1			
030	195267-4	Shear blade assembly set		1	*		
C10	188369-3	Oil vessel set		1	*		
030-1	195267-4	Shear blade assembly set	O	1			
C10	188369-3	Oil vessel set		1			
031	140451-6	Under cover complete		1			
A01	452055-5	Blade cover		1			
A02	457426-1	Grass receiver 160		1			
A03	198408-1	Shear blade assembly 200S set		1			
C10	188369-3	Oil vessel set		1			
A04	198401-5	Chip receiver set		1			
A05	195275-5	Blade cover set		1	*		
C10	452198-3	Storage case		1	*		
A05-1	195275-5	Blade cover set	O	1	*		
C10	452198-3	Storage case		1	*		
A05-2	195274-7	Blade cover set	O	1			
C10	452198-3	Storage case		1			
A06	456128-6	Battery cover		2			
A07C	***DC10WD	DC10WD BATTERY CHARGER		1			
A07C		COMPO-PARTS					
A07D	***DC10SA	DC10SA BATTERY CHARGER		1	*		
A07D		COMPO-PARTS			*		
A07-1D	***DC10SB	DC10SB BATTERY CHARGER	<	1			
A07-1D		COMPO-PARTS					
A08C	197390-1	Battery BL1015 set		2	*		
A08D	197402-0	Battery BL1040B set		2	*		
A08-1C	197393-5	Battery BL1016 set	<	2			
A08-1D	197406-2	Battery BL1041B set	<	2	*		
A08-2D	197406-2	Battery BL1041B set	O	2			
B01	198412-0	Grass receiver 160 set		1			
B01		INC. A01,A02,A05C10					
E01	812G42-2	Sound 83dB label		1	*		
E01-1	812G42-2	Sound 83dB label	<	1			
F02-1	195267-4	Shear blade assembly set	O	1			
F03	195274-7	Blade cover set		1			
F04	195275-5	Blade cover set		1	*		
F07	198401-5	Chip receiver set		1			

F09	198408-1	Shear blade assembly 200S set		1			
F12	198516-8	Long handle attachment set		1			
F15	198968-3	Battery BL1016 set		1	*		
F16	198969-1	Battery BL1016 set (2 pcs)		1	*		
F17-1	198970-6	Battery BL1021B set (2 pcs)	O	1	*		
F18-1	199002-2	Battery BL1041B set (2 pcs)	O	1	*		

Please state Parts No. when your order.

Print Date 03/30/2026